Replacement Parts



L1St EmberGlo® Steamer Models ES5CTS & ES5CTS18

Tap Water Operation
Designed to Operate
Without Distilled Water
Self Contained Water Supply

Automatic Timer/Push Button Operation Steamer with Water Pan

Date Codes:

Cubic Style Timer Models ES5CTS & ES5CTS18 - first construction January 2014

Replacement Model numbers for Old Style Timer Models, that are no longer manufactured and replaced with the Cubic Style Timer:

ES5TS is replaced with ES5CTS ES5TS18 is replaced with ES5CTS18

Items listed are replacement parts for the current Model ES5CTS & ES5CTS18 Tap Water Steamers and its components.

 EmberGlo Steamers do not require a separate hood for vapor produced during operation according to the Uniform Mechanical Codes per the International Conference of Building Officials Code.



Installation and Service Manual - 8449-96

Models	Description	Volts	BOMs
1500W ES5CTS ES5CTS	Timer Operation with Water Pan Timer Operation with Water Pan	120V 240V	5400754 5400756
<i>1800W</i> ES5CTS18	Timer Operation with Water Pan	120V	5400755




EmberGlo A Div of Midco® International Inc 4140 West Victoria Street Chicago, Illinois 60646 toll free 866.705.0514 tel 773.604.8700

fax 773.604.4070
web www.emberglo.com
e-mail sales@emberglo.com

AVOID ERROR IN PARTS SELECTION. When ordering use complete MIDCO Part Number and Description. Furnish Burner Model Number, Bill of Material Number and Serial Number (if available) from the specification plate found on the product.

IMPORTANT: Availability of parts as well as specifications are subject to change without notice. Please consult factory for item availability.





ES5CTS & ES5CTS18 Parts List

					501 5	ee Pose 1910 Turts P	7151
Part	#	Description	Qty	Part	#	Description	Qty
1A	1420-80R	Lid Assembly	1	30	1409-60	Tube Clip	1
1B	1420-81R	Lid Assembly - 1800 Series Only	1	31	1402-70	Water Inlet Assembly	1
2	1435-00	Lid Handle Replacement Kit	1	32	1412-60	Nozzle Spring	1
3	5608-50	Food Pan Grid	1	33	1411-20	Water Nozzle with Spring	1
3B	5608-51	Food Pan Grid 1.5" Tall	1	34	1415-70	TS Water Tube	1
4	1401-90	ES5 3-Hole Food Pan	1	35	8483-37	1/8F X 1/4T Comp EL	1
5	1401-21	Control Box Cover	1	36	8483-15	1/8" Brass Street EL	1
6A	1401-61	ES5 Generator - 220V, 1500W	1	37	1417-00	TS Pump Bracket	1
6B	1401-63	ES5 Generator - 120V, 1800W	1	38	8483-36	1/8" Brass EL	1
6C	1401-64	ES5 Generator - 120V, 1500W	1	39	8406-92	Recycle Timer 606 - External Resistor *	1
7	1401-30	ES5 Bulb Clamp	1	40	8406-64	One Shot Timer 844B - ES5CTS / CTS18	1
8	1409-00	Stiffener	1	41	8423-22	Push Button Switch	1
9	8451-89	Plug Button HS51156-K1110	1	42	5622-00	Name Plate	1
10	1400-40	Shell	1	43	8408-92	1 Meg Ohm Potentiometer - ES5CTS / CTS	18 1
11A	1403-70	ES5 Power Cord-120V	1	44	1416-80	Steamer Cube &	
11B	1415-10	ES5 Power Cord-220V	1			Pump Bracket - ES5CTS / CTS18	1
12	8457-46	Strain Relief	1	45	8423-43	On/Off Toggle Switch - ES5CTS / CTS18	1
13	1401-10	Rear Bottom	1	46	8408-66	Pilot-Light Ready-120V	1
14	1407-10	Water Pan Shell	1	47	8423-15	On/Off Rocker Switch	1
15	1406-50	Water Pan Slide	1	48	1417-23	Front Panel - ES5CTS / CTS18	1
16	5661-80	Aluminum Leg	4	49	8445-27	Control Knob - ES5CTS / CTS18	1
17	8450-25	Socket Tip	4	50	8423-35	Mode Rocker Switch - ES5CTS / CTS18	1
18	1407-70	Leg Channel	1				
19	1402-10	Water Pan	11				
20	1411-00	Water Pan Baffle Set	1				
21	8445-01	Cover Knob	1				
22	1408-90	Water Pan Front	11	I	Not Shown		
23	1416-00	TS Dip Tube Assembly	11		1420-00	Spring Bar	2
24	8483-14	1/8" x 1/4" Straight Connector	11		1420-40	ES5 Hinge Spring	2
25	1425-00	Buzzer Assembly – 120V	11		1421-45	Back Hinge Kit (Less Spring Bar & Sprin	ıg) 1
26A	1417-40	TS Manual Front Bottom	1		8451-74	Strainer	1
26B	1417-41	TS Front Bottom -220V	11				
27	8484-76	Shorty Bush B-500-375	11		Accessories	- Not Shown	
28	1412-41	Thermal Fuse/ Thermostat Kit	11		5608-70	Three in 1 Basket Kit w/ Handle	
29A	1435-12	Pump Replacement Kit	11		5682-60	Tortilla Rack - Grid Style	
29B	1423-05	Pump Assembly 220/1/50	11		5608-72	1/2 Size Basket w/ Handle	
					5608-73	Two of 1/4 Size Basket w/ Handle	
				;	5609-15	1/2 Size Perforated Water Pan	
					8450-62	Steam Generator Cleaning Brush	
					2070610	Egg Poacher 4 Cup	
					0070045	E B 00	

* NOTE: Old Timer Style Models - ES5TS, ES5TS18 & ES5PCS

The EmberGlo **ES5TS**, **ES5TS18 & ES5PT** timer model steamers will not be manufactured after January 2014. The timers in these models are no longer available and were replaced with cubic style timer (CT Timers) models as follows:

ES5TS - replace with ES5CTS

ES5TS18 - replace with ES5CTS18

2070615

ES5PT - replace with ES5PCS

Egg Poacher 6 Cup

Aside from the timers all of the other parts remain the same. Call the manufacturer or your local representative for further details or assistance on these old style timer steamers.

ES5CTS & ES5CTS18 - Replacement Parts

ADJUSTABLE HINGE FOR 2-POSITION LID OPENING (60° OR 90° OPEN)

First construction January 29, 1990 (date code 0590). Steamers built before this date featured a 90° opening lid. Replacement parts for the early construction are no longer available. When replacing order Part Number 1421-45 ADJUSTABLE HINGE RETROFIT KIT.

Part # or	Description	Qty
Item #		
1	Adjustable Upper Hinge	1
2	Lid Stop Rivetment	1
3	Upper Hinge Bar	1
4	Adjustable Lower Hinge	1
5	5/16" x 3/16" O-Ring	2
	Not Shown - (Sold Separately)	
1420-00	Spring bar	2
1420-40	ES5 Hinge Spring	2

